



# Asus ROG GL551J Optical Drive Replacement

An optical drive replacement guide for the Asus ROG GL551J

Written By: Philip Muino



## INTRODUCTION

An optical drive replacement guide for the Asus ROG GL551J.

---

### TOOLS:

- [Phillips #000 Screwdriver](#) (1)
-

## Step 1 — Battery



- Lay device on a flat surface with battery facing up.

## Step 2




- Locate latch below battery and push right.

### Step 3



- Battery should release upwards. Pull battery out.

### Step 4 — Optical Drive



- Locate and unscrew the screw which connects the optical drive to the chassis



## Step 5



- Grasp the edge of the optical drive

## Step 6



- Pull on the optical drive gently. With little resistance, the optical drive should just slide out

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-27 01:30:07 AM.